

NEPTUN HWW 6000 INOX-INOX PUMPE

NEPTUN HWW 6000 INOX-INOX			
CODE	POS.NR.	DESCRIPTION	
7104000	1	Kasten Kondensatorbox	BASE CAPACITOR BOX
7102236	2	KONDENSATOR	CAPACITOR
7103794	3	Abdeckung Kondensatorbox	COVER CAPACITOR BOX
0360341	4	SCHRAUBE	SCREW
0270431	5	SCHRAUBE	SCREW
0270431	6	SCHRAUBE	SCREW
7002011	7	Kabelhalter	CABLE LOCKER
7103831	8	KABELFUHRUNG	CABLE HOLDER
0360341	9	SCHRAUBE	SCREW
3000299	10	Klemmbrett	TERMINAL BOX
7105674	11	SCHRAUBE	SCREW
7102174	12	Lüfterabdeckung	FAN COVER
7101796	13	Lüfterrad	FAN
7101797	14	Motordeckel	SHIELD
1000250	15	Dichtung	SPRING WASHER
7103644	16	Stator	STATOR
1440100	17	Kugellager	BALL BEARING
7106286	18	Rotor	ROTOR
1440110	19	Kugellager	BALL BEARING
7105810	20	Ein / Ablassschraube	CAP
7105512	21	PUMPEGEHAUSE	PUMP BODY
0160812	22	SCHRAUBE	SCREW
1310517	23	O-RING	O-RING
0270422	24	SCHRAUBE	SCREW
0830512	25	SCHEIBE	WASHER
7106287	26	Ventil	VALVE
7106284	28	Düse	NOZZLE
7107071	29	SCHRAUBE	SCREW
0030462	30	SCHRAUBE	SCREW
0830572	31	SCHEIBE	WASHER
7103552	32	LAUFRAD	IMPELLER
7103574	33	DIFFUSORSCHLEIBE	DIFFUSER
7106282	34	Flansch	FLANGE
7106289	35	Abstandshalter	SPACER
1010112	36	Dichtung	SPRING WASHER
7106529	37	SCHEIBE	WASHER
3090779	38	mechanische Dichtung	MECHANICAL SEAL
7108020	39	Thermoschutz	THERMAL PROTECTOR
7107897	40	Scheibe	PLATE
0650002	41	Mutter	NUT
1311537	42	O-RING	O-RING
7108003	43	mechanische Dichtung	MECHANICAL SEAL
7107900	44	Flansch	FLANGE
7103833	45	Scheibe	PACKING
7107402	46	Pumpenflansch	SUPPORT
0640052	47	Mutter	NUT

NEPTUN HWW 6000 INOX-INOX Tank

NEPTUN HWW 6000 INOX-INOX			
CODE	POS.NR.	DESCRIPTION	
7102312	1	Panzerschlauch	HOSE
7250954	2	Dichtung	GASKET
0030862	3	SCHRAUBE	SCREW
7105683	4	Flansch	FLANGE
7103110	5	Ventil	VALVE
7102903	6	Wassersack	WATER BAG
7103097	7	Tank	TANK
7105281	8	Mutter	NUT
7103111	9	Ein / Ablassschraube	CAP
7105280	10	SCHRAUBE	SCREW
7104230	11	KABEL	CABLE
7104369	12	Druckschalter	PRESSURE SWITCH
7107607	13	Pumpe	PUMP
7104982	14	Manometer	MANOMETER
7101135	15	WINKEL	RACCORD
7202683	16	KABEL	CABLE